



SR 500

Spare parts / Accessories



No.	Description	Ordering No.
1.	Fan unit SR 500, bare	R06-0110
2.	Gasket	R06-0107
3.	Combined filter A1BE2K1-Hg-P3 R, SR 599	H02-7312
4.	Gas filter A1BE2K1, SR 597	H02-7212
5.	Gas filter ABE1, SR 515	H02-7112
6.	Gas filter A2, SR 518	H02-7012
7.	Filter adapter SR 511	R06-0105
8.	Particle filter P3 R, SR 510	H02-1312
9.	Pre-filter SR 221	H02-0312
10.	Pre-filter holder SR 512	R06-0106
11.	Particle filter P3 R, SR 710	H02-1512
12.	Pre-filter holder SR 5153	R01-0604
13.	Steel net disc SR 336	T01-2001
14.	Asbestos kit SR 509	T06-0105
15.	STD Standard battery, 2,2 Ah HD Battery, 3,6 Ah	R06-0102 T06-0101
16.	Battery charger SR 513	R06-0103
17.	Charger stand SR 506 Charger and chargerstand SR 516	T06-0108 T06-0111
18.	Belt PES SR 508 Rubber belt SR 503	R06-0101 T06-0104
19.	Leather belt SR 504	T06-0103
20.	Flow meter SR 356	R03-0346
21.	Storage bag SR 505	T06-0102
22.	Splash cover SR 514	T06-0114
23.	Cleaning wipes 50/box	H09-0401