


SPAREPARTS LIST FLAIR 600 GOUGING TORCH



Product nr	Description	Draw nr	Packing
E2031	Insulation cap	2	1
E2043	Screw MRX 4 x 10 mm Flair	1	1
E2034	Lever insulation	6	1
E2038	Push-button and link	14	1
E2035	Handle	13	1
E2037	Push-button	11	1
E2040	Safety ring	12	1
E2048	Copper sealing ring for Flair monocable and gouging torch	15	1
E2042	Valve	10	1
E2041	Valve seat	16	1
E2039	Hinge pin	8	1
E2044	Spring Flair	7	1
E2033	Body	9	1
E2036	Injection nozzle	4	1
E2032	Brass lever	3	1

Klingstrand AB

Box 12173 402 42 Göteborg, Sweden Tel: +46(0)31-14 29 70 Fax: +46(0)31-14 43 81
www.klingstrand.se info@klingstrand.se